

# MOSQUITO CATCHER™

## Owner's Use & Care Manual

#61001



**Congratulations!** You are now an owner of the Mosquito Catcher™ product. This product lures and collects mosquitoes into the unit, reducing pests from your yard and porch. The unit is easy to set up and run. Simply unpack, select the proper leg size, plug it in and it's operating.

Catching mosquitoes is NOT a simple, single day or one-week proposition...it is a continual effort. On some days you will collect many mosquitoes and on other days you will collect none. Because you collect no mosquitoes on a single day does NOT mean that the mosquitoes are all gone. Mosquito populations vary and weather conditions greatly affect when mosquitoes are active. The unit is designed to run on a long-term basis. Plug the unit in, turn it on and let it run.

### GENERAL SAFETY INFORMATION

This manual contains important information about the assembly, operation and maintenance of the product. General safety information is included in this Owner's Use & Care Manual. Attention should be paid to information containing the alert symbols: WARNING, CAUTION, and DANGER.

Keep this manual for future reference and to educate users of the product and safety requirements. This manual is to be used in conjunction with product labeling.

**READ OWNER'S MANUAL COMPLETELY BEFORE SETTING UP OR USING PRODUCT**

## GENERAL SAFETY INFORMATION (Continued)

Safety precautions are essential when electrical equipment is involved. These precautions are necessary when setting up, using, storing and servicing the product. Using this product with the respect and caution demanded will reduce the possibilities of personal injury and property damage.

The following symbols are used throughout this guide. Always heed these precautions, as they are essential when using any electrical or mechanical equipment.



**DANGER** - indicates an imminently hazardous condition which, if not avoided, will result in death or serious injury, or property damage.



**WARNING** - indicates a potential hazardous condition which, if not avoided, may result in death or serious injury, or property damage.



**CAUTION** - indicates a potentially hazardous condition which, if not avoided, may result in moderate to minor personal injury, or property damage.



**DANGER:** To reduce the risk of electric shock, this product has a 3-conductor cord and 3-prong grounding-type plug that has a third (grounding) pin. This plug will only fit into a grounding-type power outlet. If the plug does not fit into the outlet, contact qualified personnel to install the proper outlet. Do not alter the plug in any way. To disconnect unit, grasp the plug, not the cord.



**WARNING:** Improper setup, usage or service of this product may result in personal injury or property damage. Read these instructions thoroughly before installing or servicing this product.

**WARNING:** This product is intended for Outdoor Use Only.



**DANGER:** Failure to comply with the instructions and precautions provided with this product may result in death, serious personal injury or property damage, from electric shock. Only persons who can understand and follow the instructions in the manual should use or service this product.



**DANGER:** Potential of electric shock if unit is operated in rain or sprinkler areas. Keep unit dry. To reduce the risk of electric shock, keep extension cord connection dry and off the ground.

This product must be supplied with 120VAC, 60 Hz, and be connected to an individual, properly grounded branch circuit, protected by a 15 or 20 Amp circuit breaker or fuse. Wiring must be a minimum of 2 wire with ground, No. 16 minimum.



To avoid risk or injury, do not allow children to play around product. Do not abuse, sit on or stand on product. **WARNING:** Plastic bags may cause a choking hazard for children. Keep out of reach of children. Dispose of properly.



**WARNING:** If using an extension cord or extension cord connections, use only UL Listed products marked as "Suitable for Use with Outdoor Appliances". Use extension cords marked SJW-A, SJEW-A or SJTW-A only. The electrical rating of the extension cord must be greater than the rating of the product. Use 16 gauge minimum.

Use only extension cords which have 3-conductor cords and 3-prong grounding-type plugs, which accept the product's plug. Replace or repair damaged cords. Don't abuse cord - Never carry product by cord or yank cord to disconnect from receptacle. Keep cord from heat, oil and sharp edges.

When not in use, disconnect product from receptacle and store indoors. Disconnect product from receptacle when replacing fuse. Keep out of Reach of Children.

Do not insert foreign objects into this product. Do not clean this product with a water spray or similar method. Do not use this product in a manner other than specified.

## READ OWNER'S MANUAL COMPLETELY BEFORE SETTING UP OR USING PRODUCT



### CONTENTS

- 1 – Mosquito Catcher™
- 1 – Set of short legs (for hard surface use)
- 1 – Set of long legs (for use in grass)
- 1 – Set of screws to attach legs (inside collection drawer)
- 1 – Owner's Use & Care Manual
- 1 – Warranty Card

### INSTRUCTIONS FOR SETUP

1. Remove Mosquito Catcher™, screws (4), short legs (4) and long legs (4) from carton. Remove packing material and plastic bag. Dispose of packaging material and plastic bag properly.
2. Select the proper legs for your application.
  - Short legs are for use on hard surfaces, such as patios, decks, tables and floors.
  - Long legs are for use on grassy surfaces where the long grass might interfere with the bottom air exit.

**DO NOT RUN UNIT IN GRASS LONGER / TALLER THAN 5" (125 mm).**

3. Fasten selected legs onto bottom of unit with screws (see drawing).

### INSTRUCTIONS FOR USE

1. Place unit in desired running location.
2. Plug unit into 120VAC, 60 Hertz power.
3. Bottom air exit must NOT be obstructed.
4. Turn unit ON to desired operating mode:
  - Manual - runs continually
  - Auto - light sensor activated, runs only during dark / night time hours
5. Weekly, or as necessary, remove collection drawer and discard mosquitoes. Turn unit to OFF during cleaning operation.

### MOVING UNIT

1. Before moving unit, turn OFF and unplug from electric source.

### FUSE

1. Under overload conditions, fuse may need replacement. Replace with standard 120VAC, 10A fuse. Disconnect from electrical source before replacing fuse.

### REPLACEMENT PARTS ORDERS

Please contact your local retailer for replacement parts, or contact us at [customerservice@rushhampton.com](mailto:customerservice@rushhampton.com) or 1-800-327-7175 (1-407-324-5887).

1. FUSE - 120VAC, 10Amp Buse-type
2. Legs



#### IMPORTANT NOTE:

For unit to operate properly, collection drawer must be closed completely.

## WARRANTY

Rush Hampton warrants this product for parts and labor for a period of one year from date of purchase. If you have problems or difficulties with your Mosquito Catcher, please contact Rush Hampton with your questions or concerns, at [customerservice@rushhampton.com](mailto:customerservice@rushhampton.com) or 1-800-327-7175 (1-407-324-5887).

### LIMITED WARRANTY

All products covered by this instruction sheet are warranted to purchasers of the product against defects in workmanship and materials for one year from date of any sales by Rush Hampton. ANY IMPLIED WARRANTIES INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY ARE ALSO LIMITED TO THIS ONE YEAR PERIOD. SOME STATES DO NOT ALLOW LIMITATIONS OR INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY DOES NOT APPLY TO DAMAGE FROM ACCIDENT, MISUSE OR ALTERATION, NOT WHERE THE CONNECTED VOLTAGE IS MORE THAN FIVE (5%) PERCENT ABOVE THE NAMEPLATE VOLTAGE, NOT TO EQUIPMENT IMPROPERLY INSTALLED OR WIRED OR MAINTAINED IN VIOLATION OF THIS INSTRUCTION SHEET. This warranty is valid in the fifty (50) states of the United States and Canada. NO OTHER WRITTEN OR ORAL EXPRESS WARRANTY APPLIES. NO EMPLOYEE, AGENT, DEALER OR OTHER PERSON IS AUTHORIZED TO GIVE ANY WARRANTIES ON BEHALF OF RUSH HAMPTON.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

THE CUSTOMER SHALL BE RESPONSIBLE FOR ALL COSTS INCURRED IN THE REMOVAL AND REINSTALLATION AND SHIPPING OF THE PRODUCT FOR REPAIR. Subject to the foregoing and within the limitation of this warranty inoperative units should be returned to Rush Hampton, who is the warrantor, at 4200 ST. John's Parkway, Sanford, Florida 32771 USA, and Rush Hampton will, at its own expense, repair or replace the product for one year from the date of sale. IT IS AGREED THAT SUCH REPAIR OR REPLACEMENT IS THE EXCLUSIVE REMEDY AVAILABLE AND THAT RUSH HAMPTON IS NOT RESPONSIBLE FOR DAMAGES OF ANY KIND INCLUDING INCIDENTAL AND CONSEQUENTIAL DAMAGE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU.

Merchandise returned to Rush Hampton must be accompanied by a return authorization and service identification tag, both available from the above location. When requesting return authorization include all catalog numbers on the product.



Mosquito Catcher™ manufactured in China

**RUSH HAMPTON**

Rush Hampton® is a brand of TekQuest Industries  
Sanford, Florida 32771

Mosquito Catcher™ and Rush Hampton® are trademarks of TekQuest Industries



LISTED